

BI-02.13 Routine tyre inspection

(Accountable - Engineering Manager (Site) (Unassigned))

Expectations

Mobile equipment with compromised tyres does not operate.

Specify

Earth moving equipment tyres are regularly inspected to confirm that they will not lead to an elevation of fire risks. Sites employ or retain appropriate workers with expertise to check, proof test and replace/dispose tyre components as needed.

Earth moving equipment tyres are regularly inspected by:

- Operators as part of equipment pre-use checks
- Tyre specialists

Equipment with low pressure or damaged tyres is removed from service.

Implement

As per tyre maintenance schedule

Monitor

Tyre condition reports including service life monitoring