

## CFM-LR-02 Solid fuel, components present on mobile equipment smoulder or burn - not able to extinguish

After a component fire is detected, it cannot be extinguished using fire suppression system or fire extinguishers, caused by:

- \* FSS nozzles not being directed at/near the component
- \* Inaccessibility of component - cannot be extinguished from a safe location (e.g. external to the machine)

Credible Failure mode is addressed by:

- 🛡️ BI-01.43 Required system health checks before mobile equipment operation - information for operator by vehicle type specifying: access and escape, alarms, fire suppression, auto shutdowns and other relevant protective systems
- 🛡️ BI-02.07 Regular checking and maintenance of brakes, steering and tyres
- 🛡️ BI-02.12 Serviced and checked fire extinguishers on mobile equipment
- 🛡️ BI-09B.03 Operator Fire Training